

How to apply your Hotfix Film Sample



Using scissors, trim design to 1/8" from the top and bottom edges. (this step only necessary when "Layering" colors)



Remove clear backing film from transfer.



Align pieces together. Use the 1/8" edge to "stick pieces together" to create one transfer.



Center transfer on garment. Place Teflon sheet over transfer. Press for 7 seconds, 350° with medium to firm pressure. Allow transfer to COOL COMPLETELY. Slowly, remove clear backing from top blue section of transfer. KEEP BACKING!



Place "VOTE" Transfer above image.

Place star nailheads in the blank stars. Place backing over stars to hold in place while pressing.

Place Teflon sheet over transfer. Press for 10-15 seconds, 350° with medium to firm pressure.



Allow transfer to COOL COMPLETELY. Slowly, remove clear backing.

