



## Hotfix Film Application Instructions

Pre-press fabric to remove any moisture before pressing films. Moisture in fabric may prevent film from bonding properly. Remove clear poly film on the back of transfer before placing on garment. Use a Teflon sheet between the image and heat plate to prevent scorching.

### **Flock, Glitter, Hologram, & Metallic Films:**

Temperature: 320°F

Duration: 10-15 Seconds (15-20 seconds for Flock)

Pressure: Medium to Firm

Carrier sheet removal: COLD – This is a cold peel application. Allow design to cool completely before removing carrier sheet.

### **EasyWeed:**

Temperature: 305°F

Duration: 10-15 Seconds

Pressure: Medium

Carrier sheet removal: Hot or Cold peel application. EasyWeed is great for "layering" multiple colors. When "layering" press quickly for 1-2 seconds and peel carrier away, place next layer on previous layer and repeat. When last layer is applied press for the full pressing time.

**Please note that heat presses vary. You may find that you need to adjust your temperature or pressing duration. The above is a good "starting place".**